



Installation Instructions

6747 Whitestone Rd • Baltimore, MD 21207 • (410) 298-4343 • FAX: (410) 298-3579
www.atiperformanceproducts.com

STARTER BLOCK PLATE

Part # 915116

The ATI Starter Block Plate will fit all C4, FMX, C6, AOD, and manual transmissions behind small block Windsor and Cleveland engines. Installation is easy, the only modifications to be made are to the starter area and this is only if you have a 164 tooth (large bell) flywheel. This can be determined by counting the flywheel teeth or by matching the new plate to the old one.

If you have a 164 tooth set-up the crescent shaped starter area needs to be removed. This can be done along perforations with hacksaw or pliers Smooth out any remaining nubs with a file. Install the plate onto the dowel pins in the block. This will be a tight fit. Using a socket to tap the plate on helps.

INST. #915116-I 10/2006



Installation Instructions

6747 Whitestone Rd • Baltimore, MD 21207 • (410) 298-4343 • FAX: (410) 298-3579
www.atiperformanceproducts.com

STARTER BLOCK PLATE

Part # 915116

The ATI Starter Block Plate will fit all C4, FMX, C6, AOD, and manual transmissions behind small block Windsor and Cleveland engines. Installation is easy, the only modifications to be made are to the starter area and this is only if you have a 164 tooth (large bell) flywheel. This can be determined by counting the flywheel teeth or by matching the new plate to the old one.

If you have a 164 tooth set-up the crescent shaped starter area needs to be removed. This can be done along perforations with hacksaw or pliers Smooth out any remaining nubs with a file. Install the plate onto the dowel pins in the block. This will be a tight fit. Using a socket to tap the plate on helps.

INST. #915116-I 10/2006