



ADAPTER KIT

TOYOTA SUPRA 2JZ 6 CYLINDER TO CHEVY PG AND TURBO

Part # 915219

PARTS LIST:

- 1 (915181) Aluminum Adapter Plate
- 1 (915080) Crankshaft Adapter
- 1 (915471) SFI Flexplate, 115 Tooth 10 Pitch
- 8 (951362) Crank Bolts
- 1 (950122) Hardware Kit
 - Plate to Block Hardware
 - 5 PCS (951360) 12MM x 1.25 x 30MM Hex Head Cap Screws
 - 5 PCS (953021) 1/2" AN Flat Washers
 - 2 PCS (951043) 3/8-16 x 2-1/2" Hex Head Cap Screws
 - 2 PCS (953050) 3/8" AN Flatwashers
 - 2 PCS (951462) 7/16-14 x 1-1/4" Hex Head Cap Screws
 - 2 PCS (951361) 10MM x 1.25 x 30MM Hex Head Cap Screws
 - 4 PCS (953010) 7/16" AN Flatwashers

 - Transmission to Plate Hardware
 - 6 PCS (951390) 3/8" x 1-3/4" Studs - **See note 1!**
 - 6 PCS (952000) 3/8-24 Hex Nuts
 - 6 PCS (953050) 3/8" AN Flatwashers
 - 2 PCS (958000) 3/8" x 5/8" Dowel Pins

NOTE:

1. For Dedenbear cases, use 4 pieces #951390 (3/8 x 1-3/4" studs) and 2 pieces #951391 (3/8 x 2 5/16 studs). Use two longer studs on lower case bolt holes on the right and left.