



## **ADAPTER KIT RB-26 NISSAN TO CHEVY POWERGLIDE AND TURBO**

Part # 915222

### **PARTS LIST:**

- 1 (915200) Aluminum Adapter Plate
- 1 (915100) Crankshaft Adapter
- 1 (915480) SFI Flexplate
- 1 (950250) Hardware Package
  - 6 PCS (951360) 12 MM x 1.25 x 30 MM Hex Head Cap Screws
  - 3 PCS (951370) 10 MM x 1.5 x 30 MM Flat Socket Head Screws
  - 1 PC (951380) 10 MM x 1.5 x 30 MM Socket Head Cap Screw
  - 5 PCS (951390) 3/8" X 1-11/16" Studs - **See note 4!**
  - 6 PCS (952000) 3/8-24 Hex Nuts
  - 6 PCS (953050) 3/8" AN Flatwashers
  - 2 PCS (958000) 3/8" x 5/8" Dowel Pins

### **NOTE:**

1. Do not use Loctite on screws which mount adapter plate to block.
2. Use 10 MM x 1.5 x 30 MM socket head cap screw where hollow dowel in motor is located.
3. Flexplate is placed on the crankshaft, then the crankshaft adapter is bolted on.
4. For Dedenbear cases, use 4 pieces #951390 (3/8 x 1 11/16 studs) and 2 pieces #951391 (3/8 x 2 5/16 studs). Use two longer studs on lower case bolt holes on the right and left.