



ADAPTER KIT DODGE R5 BLOCK TO CHEVY TURBO WITH SFI FLEXPLATE 6 BOLT, 130 TEETH, INTERNAL BALANCE

Part # 915252

PARTS LIST:

- 1 (915135) Aluminum Adapter Plate
- 1 (915630) Crankshaft Adapter
- 1 (915650) SFI Flexplate
- 1 (950175) Hardware Package
 - 2 PCS (951230) 7/16-14 x 1" Grade 5 Hex Head Cap Screws
 - 2 - Starter mounting Bolts
 - 6 PCS (951390) 3/8" x 1-11/16" Studs - **See note 3!**
 - 6 PCS (951471) 7/16-20 x 1-1/4" Crankshaft Screws
 - 5 PCS (951420) 3/8-16 x 1-1/4" Flat Socket Head Screws
 - 6 PCS (952000) 3/8-24 Hex Nuts
 - 6 PCS (953050) 3/8" AN Flatwashers
 - 2 PCS (958000) 3/8" x 5/8" Dowel Pins, Adapter Plate to Transmission
 - 2 PCS (951003) 3/8-16 x 1" Buttonhead Screws

NOTE:

1. Do not use Loctite on screws which mount adapter plate to block.
2. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on.
3. For aftermarket cases, use 4 pieces #951390 (3/8 x 1 11/16 studs) and 2 pieces #951391 (3/8 x 2 5/16 studs). Use two longer studs on lower case bolt holes on the right and left.