

## ADAPTER KIT

### CHRYSLER B OR RB ENGINES 383-400-426-440 WITH DRIVER SIDE STARTER POCKET TO CHEVY POWERGLIDE AND TURBO WITH SFI FLEXPLATE 6 BOLT, 130 TEETH, INTERNAL BALANCE

PART # 915260

#### PARTS LIST:

- 1 (915150) Aluminum Adapter Plate
- 1 (915630X) Crankshaft Adapter
- 1 (915650X) SFI Flexplate
- 1 (950180) Hardware Package
  - 2 PCS (951230) 7/16-14 x 1" Grade 5 Hex Head Cap Screws
  - 6 PCS (951390) 3/8" x 1-11/16" Studs - **See note 4!**
  - 6 PCS (951471) 7/16-20 x 1-1/4" Crankshaft Screws
  - 4 PCS (951420) 3/8-16 x 1-1/4" Flat Socket Head Screws
  - 6 PCS (952000) 3/8-24 Hex Nuts
  - 6 PCS (953050) 3/8" AN Flatwashers
  - 2 PCS (958000) 3/8" x 5/8" Dowel Pins

#### NOTE:

1. Do not use Loctite on screws which mount adapter plate to block.
2. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on.
3. This kit requires the converter to have the Powerglide bolt circle that fits the **inner** bolt circle on the flexplate. The three (3) holes close to the ring gear are **not** usable.  
  
No part of the torque converter should contact the ring gear!
4. For aftermarket cases, use 4 pieces #951390 (3/8 x 1 11/16 studs) and 2 pieces #951391 (3/8 x 2 5/16 studs). Use two longer studs on lower case bolt holes on the right and left.