



ADAPTER KIT
CHRYSLER B OR RB ENGINES 426 HEMI WITH
DRIVER SIDE STARTER POCKET TO CHEVY POWERGLIDE
AND TURBO WITH SFI FLEXPLATE
8 BOLT, 130 TEETH, INTERNAL BALANCE
FOR PRO MOD USING FUEL CRANKS

PART # 915290X

PARTS LIST:

- 1 (915150X) Aluminum Adapter Plate
- 1 (915640XF) Crankshaft Adapter
- 1 (915660X) SFI Flexplate
- 1 (950190X) Hardware Package
 - 2 PCS (951050) 7/16-14 x 1-1/2" Grade 5 Hex Head Cap Screws
 - 2 PCS (951230) 7/16-14 x 1" Grade 5 Hex Head Cap Screws
 - 6 PCS (951390) 3/8" x 1-11/16" Studs - **See note 3!**
 - 4 PCS (951420) 3/8-16 x 1-1/4" Flat Socket Head Screws
 - 8 PCS (951035) 1/2-20 x 1-1/4" 12 PT Extreme Duty Bolts
 - 6 PCS (952000) 3/8-24 Hex Nuts
 - 6 PCS (953050) 3/8" AN Flatwashers
 - 2 PCS (958000) 3/8" x 5/8" Dowel Pins

NOTE:

1. Do not use Loctite on screws which mount adapter plate to block.
2. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on.
3. For aftermarket cases, use 4 pieces #951390 (3/8 x 1 11/16 studs) and 2 pieces #951391 (3/8 x 2 5/16 studs). Use two longer studs on lower case bolt holes on the right and left.