



# Installation Instructions

6747 Whitestone Road • Gwynn Oak, MD 21207 • (410) 298-4343  
FAX: (410) 298-3579 • www.atiracing.com

## STUD KIT - SUPERCASE TO BELL

Part #950263

### PACKING LIST

- (6) #951394 7/16-14 x 1/2" X 3/8-24 x 5/8" Stud
- (6) #952006 3/8-24 Flange Nut
- (6) #953050 3/8" AN Flat Washer

Packed by: \_\_\_\_\_

1. Clean the case holes thoroughly before installing the studs in the case.
2. Using Red Loctite, install 7/16" course thread side of stud into the case with a stud driver or with 2 nuts. Tighten the studs until the threads are flush with the case.
3. Slide the bell over the studs and install one (1) washer and one (1) nut on each stud. **Do not use Loctite!** Tighten the six (6) nuts to 35 ft/lb in a criss-cross fashion.