



Installation Instructions

6747 Whitestone Road • Baltimore, MD 21207 • (410) 298-4343 • FAX: (410) 298-3579
www.atiracing.com

CRANK BOLT KIT WITH REUSABLE BOLT

Fits LS1, LS6 5.7L and 6.0L

Part # 951503

1. Apply high temperature RTV to both sides of the washer prior to installation.
2. Use #262 Red Loctite® on threads. Torque to 225 ft/lbs.



PLEASE NOTE! DO NOT RE-TORQUE! IT WILL BREAK THE LOCTITE® LOOSE!