



# Installation Instructions

6718 Whitestone Road • Gwynn Oak, Maryland 21207 • (410) 298-4343  
FAX: (410) 298-3579 • [www.atiracing.com](http://www.atiracing.com)

## **SUPER PUMP FOR POWERGLIDES**

**Part #205032 - #205038**

When installed with a steel drum, use the bearing included with the Super Pump.

When installed with an ATI aluminum drum, use the bearing included with the aluminum drum.  
Remove the bearing from the Super Pump and install ATI spacer #982170 on the pump.

**Be sure to check for correct end play.**