



Installation Instructions

6718 Whitestone Road • Gwynn Oak, MD 21207 • (410) 298-4343
FAX: (410) 298-3579 • www.atiracing.com

ADAPTER KIT

CHRYSLER B OR RB ENGINES 426 HEMI WITH PASSENGER SIDE STARTER POCKET TO CHEVY POWER- GLIDE AND TURBO WITH SFI FLEXPLATE 8 BOLT, 130 TEETH, INTERNAL BALANCE

FOR PRO MOD USING FUEL CRANKS

PART # 915291X

PARTS LIST:

- (1) #915140X Aluminum Adapter Plate
- (1) #915640XF Crankshaft Adapter
- (1) #915660X SFI Flexplate
- (1) #950190X Hardware Package
 - 2 PCS #951050 7/16-14 x 1-1/2" Grade 5 Hex Head Cap Screws
 - 2 PCS #951230 7/16-14 x 1" Grade 5 Hex Head Cap Screws
 - 6 PCS #951390 3/8-16 x 1-3/4" Studs - **See note 3!**
 - 4 PCS #951420 3/8-16 x 1-1/4" Flat Socket Head Screws
 - 8 PCS #951035 1/2-20 x 1-1/4" 12 PT Extreme Duty Bolts
 - 6 PCS #952000 3/8-24 Hex Nuts
 - 6 PCS #953050 3/8" AN Flatwashers
 - 2 PCS #958000 3/8" x 5/8" Dowel Pins

NOTE:

1. Do not use Loctite on screws which mount adapter plate to block.
2. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on.
3. For aftermarket cases, use 4 pieces #951390 (3/8-16 x 1 3/4 studs) and 2 pieces #951391 (3/8 x 5/8 studs). Use two longer studs on lower case bolt holes on the right and left.