



Installation Instructions

6718 Whitestone Road • Baltimore, MD 21207 • (410) 298-4343
FAX: (410) 298-3579 • www.atiracing.com

CRANK BOLT KIT WITH REUSABLE BOLT

Fits LS1, LS2, LS3, LS6 & LSA 5.7L, 6.0L and LT1/LT4 WET SUMP

Part #951503 - 951359

1. Apply high temperature RTV to both sides of the washer prior to installation.
2. Use #262 Red Loctite® on threads. Torque to 230 ft/lbs.



**PLEASE NOTE! DO NOT RE-TORQUE! IT WILL BREAK
THE LOCTITE® LOOSE!**

INST. # 951503-I 8/2022



Installation Instructions

6718 Whitestone Road • Baltimore, MD 21207 • (410) 298-4343
FAX: (410) 298-3579 • www.atiracing.com

CRANK BOLT KIT WITH REUSABLE BOLT

Fits LS1, LS2, LS3, LS6 & LSA 5.7L, 6.0L and LT1/LT4 WET SUMP

Part #951503 - 951359

1. Apply high temperature RTV to both sides of the washer prior to installation.
2. Use #262 Red Loctite® on threads. Torque to 230 ft/lbs.



**PLEASE NOTE! DO NOT RE-TORQUE! IT WILL BREAK
THE LOCTITE® LOOSE!**

INST. # 951503-I 8/2022