



## Assembly Instructions

6718 Whitestone Road • Baltimore, Maryland 21207 USA • (410) 298-4343  
FAX: (410) 298-3579 • www.atiracing.com

### **NISSAN VR38 ADAPTER KIT**

Part # 915225

### **Installation of Trigger Wheel**

The trigger and ring mount to the engine side of flexplate.

1. Align the dowel pins with the holes in the flexplate.
2. Make sure the trigger is in the proper OEM orientation before installing the flexplate on the engine.
3. It is not necessary, however to aid in installation, you can tig weld the dowel pins to the flexplate once the trigger is installed if preferred.