

## FLEXPLATE KIT

### FORD 289-302-351 ALL TO C6/E4OD

### 164 TEETH, INTERNAL BALANCE


PART # 915724

**PARTS LIST:**

- 1 (915601) Crankshaft Adapter
- 1 (915704) SFI Flexplate
- 1 (950142) Hardware Package
- 6 PCS (951470) 7/16-20 x 1 1/4" Counterbore Screws

**NOTE:**

1. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on.
2. The end clearance and engagement length of the starter pinion gear with the flexplate ring gear **MUST BE CHECKED** (See Figure 1). End clearance should be at least .050 inches and engagement length at least 2/3 of ring gear width. Listed below are nominal "A" distances for typical Ford Starters.

**TRANSMISSION**

C4, AOD  
C6, E4OD  
C6, E4OD

**FORD STARTER**

E4TF-11001-AA or Equiv.  
D8AF-11001-AA or Equiv.  
D1AF-11001-AA or Equiv.

**"A" DISTANCE**

.260 inches  
.430 inches  
.590 inches