

## FLEXPLATE KIT

### FORD FE ENGINES TO C6/E40D 184 TEETH, INTERNAL BALANCE

PART # 915722


**PARTS LIST:**

- (1) #915611 Crankshaft Adapter
- (1) #915702 SFI Flexplate
- (1) #950143 Hardware Package
  - 6 PCS #951480 7/16-20 x 1" Crankshaft Screws (with a head height of .225)

**NOTE:**

1. Crankshaft adapter is placed on crankshaft, then the flexplate is bolted on. Loctite 242 should be used on threads of the crankshaft screws.

2. The end clearance and engagement length of the starter pinion gear with the flexplate ring gear **MUST BE CHECKED** (See Figure 1). End clearance should be at least .050 inches and engagement length at least 2/3 of ring gear width. Listed below are nominal "A" distances for typical Ford Starters.

**TRANSMISSION**

C4, AOD  
C6, E40D  
C6, E40D

**FORD STARTER**

E4TF-11001-AA or Equiv.  
D8AF-11001-AA or Equiv.  
D1AF-11001-AA or Equiv.

**"A" DISTANCE**

.260 inches  
.430 inches  
.590 inches



ATI Flexplates are flat, not dished and require the converter to have mounting pads forward of the body.